

Anschlussbelegung der MMC/SD - Karte



PIN	MMC	SD
1	Chip Select(CS)	Chip Select(CS)
2	CMD/DI	CMD/DI
3	GND	GND
4	VCC	VCC
5	CLK/SCLK	CLK/SCLK
6	GND	GND
7	DAT/DO	DAT/DO
8	NA	NC
9	NA	NC